


ASSEMBLY INSTRUCTIONS

Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.


CAUTIONS :


1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tighten.
3. Hardware are to be kept out of reach from children.



NOTE :

Illustration images are not product images






(A)



F-Screw 6x30
X
04PCS

(B)




Hex nut 6.5x15
X
10PCS

(C)




Washer
X
10PCS

(D)




Wrench
X
01PC

(E)




Allen key M4
X
01PC

1




2

DO NOT TIGHTEN
HEX NUT COMPLETELY




X5


3



4




5




DO NOT TIGHTEN
HEX NUT COMPLETELY


6



7



DO NOT TIGHTEN
F-SCREW COMPLETELY



BE SURE TO CHECK ALL BOLTS ARE SECURELY TIGHTENED PRIOR TO USE.